

# **CONVOY TRANSPORT PTY LTD**

Occupational Health and Safety



# **Dimension Policy**

#### Scope:

For the purposes of this policy, dimension requirements relate to the height, width, length, and overhang of a heavy vehicle or combination, and its load.

#### Policy:

- Convoy Transport Pty Ltd commits to complying with all applicable state and territory Dimension regulations. No vehicle combination or load placed on a heavy vehicle or combination will exceed the relevant prescribed dimension limits for that vehicle;
- All parties to the CoR must comply with all dimension related regulations.

| OHS | Amendment<br>Record | Dimension Procedure        | Issue #: 1                 | Revision #: 0   |  |
|-----|---------------------|----------------------------|----------------------------|-----------------|--|
|     |                     | Reviewed by: Jason Haywood | Approved by: Jason Haywood |                 |  |
|     |                     | Managing Director          | Managing Dir               | naging Director |  |

### **Dimension Procedure**

#### Prior to loading:

- The driver must be presented with all relevant Dimension information prior to loading;
- The person responsible for the loading (E.g. customer, loaders) must be made aware of the vehicle type and dimension limits of the vehicle;
- All transport and shipping documentation must be accurate and not contain any false or misleading information relating to the to the height, width or length of the goods;
- Before loading, the driver must examine and record information on the dimensions of the planned load, including individual components of the load where practicable (e.g. the dimension of the load as marked on any item as advised by the supplier/manufacturer).

### Loading:

- If the planned load cannot be loaded to remain within the dimension or overhang limits of the vehicle, then the load must:
  - a. Not be loaded onto the vehicle; or,

- b. be modified to only load to the extent in compliance with the vehicle dimension limits;
- During loading the driver is responsible to direct the loader to position the load according to his vehicle limits;
- The overall height of a loaded vehicle must be safely lower than the height of any obstruction that may be encountered on the transport route (e.g. bridge or overhead wires);
- Drivers maintain authority to request adjustments to the load.

## Prior to departure:

- All loaded vehicles must be:
  - a. Inspected prior to departure to ensure the load does not exceed the dimension limits of the vehicle; and,
  - b. Is securely fastened to prevent movement that may cause a load to exceed a dimension or overhang limit;
- No vehicle is to commence a trip if dimension limits have been exceeded during loading.

#### During delivery cycle:

- All Dimension limits as above will be adhered to throughout the delivery cycle, i.e.as freight is removed or added;
- Regular checks will be implemented to ensure the load has not shifted in a manner that causes a breach of the dimension limits;
- Consider any changes in planned route does not contain obstructions that may cause contact
  due to the dimensions of the load. (seek clarification from supervisor where necessary).